

Mortise Locks

MLF Series

How to Change Handing

For all boxes (Figure 1)

- 1) Use hex key to unfasten the screw in the hole behind latchbolt (green label)
- 2) Pull latchbolt out until it is entirely away from lock case.
- 3) Rotate latchbolt to adjust handing.
- 4) Fasten the screw tightly into the hole and glue with Threadlocker (Loctite 242).

Additional Steps for Split-Hub Boxes (Figure 2)

- 5) Use blade screwdriver to push down locking piece (green label) to other side.
- 6) Handing is completely reversed.

